

Coils



EAM4

- 1½ - 5 tons
- A-Coil
- Multi-position
- R-410A TXV



END4 (1½ - 5 tons)

ENW4 (3 - 5 tons)

- N-Coil
- Upflow or downflow
- R-410A TXV



ENH4

- 2 - 5 tons
- N-Coil
- Horizontal
- R-410A TXV



EDM4

- 1½ - 5 tons
- A-Coil
- Multi-position
- R-410A TXV
- For use with legacy gas furnaces
- Warranty/service applications

Limited Warranty:**

- Parts - 10 Yrs.

Limited Warranty:**

- Parts - 10 Yrs.

Limited Warranty:**

- Parts - 10 Yrs.

Limited Warranty:**

- Parts - 10 Yrs.



EDM2

- 1½ - 5 tons
- A-Coil
- Multi-position
- R-22 TXV
- For use with legacy gas furnaces
- Warranty/service applications

Limited Warranty:**

- Parts - 10 Yrs.



ENA4

- 1½ - 5 tons
- Uncased N-Coil
- Upflow or downflow
- R-410A TXV

Limited Warranty:**

- Parts - 10 Yrs.

EMA4

- 2 - 4 tons
- Uncased N-Coil
- For manufactured housing applications
- Downflow
- R-410A TXV

Limited Warranty:**

- Parts - 10 Yrs.



EHD4

- 2 - 5 tons
- Horizontal
- R-410A TXV

Limited Warranty:**

- Parts - 10 Yrs.

** Restrictions apply. See www.GoTempstar.com for the most current and complete warranty certificate and further details.

Illustrations and photographs are only representative. Some product models may vary. As part of its commitment to quality, International Comfort Products reserves the right to change specifications on its products without notice.

© 2013 International Comfort Products